DATASHEET FFP MASKS

PROTECTION AGAINST DUST, MIST & FUMES



AIR SEAL SERIES

FFP3 R D

3700 non valved

CHARACTERISTICS



ActivForm® Mask adapts to the shape of the wearer's face.



DuraMesh® Robust mesh structure that preserves the mask's shape.



Ventex®-Valve Extra large opening to reduce heat and humidity inside the mask.



AirWave[®] Filter Long-life pleated filter for noticeably reduced breathing resistance.



Foam face seal Soft foam full face seal for a comfortable and secure fit.



R = Reusable The mask can be cleaned, disinfected and used for more than one shift.



Clip & loop strap Mask can be hung around the neck when not in use.



Dolomite clogging test Masks have passed the Dolomite clogging test, giving the user better breathing resistance for longer.



100% PVC-FREE All Moldex products and packaging are completely free from PVC. FFP3 R D 3705 with Ventex®-valve

CERTIFICATION

The Moldex Air Seal FFP-masks meet the requirements of EN 149:2001 +A1:2009. The products are CE-marked in accordance with the requirements of EU regulation (EU)2016/425. The IFA (0121) in St. Augustin (Germany) is responsible for type examination (Module B) and monitoring of production (Module D).

The products are manufactured in an ISO 9001 certified plant.

Information for the UK market: UKCA-marked in accordance with the requirements of PPE Regulation 2016/425 as brought into UK law and amended. Responsible for Module D surveillance: BSI-Assurance UK Ltd. (Identification number 0086), United Kingdom. UK Importer: Moldex/Metric AG & Co. KG · Unit 9, Glaisdale Point · Off Glaisdale Drive, Bilborough · Nottingham. NG8 4GP · Tel. +44 (0)115 985 4288 · info@uk.moldex-europe.com

MATERIALS

Filter Layer, Inner Shell, DuraMesh®: Polypropylene, Ethylene-vinyl acetate (EVA) Foam Seal: Polyolefin Clip: Polyethylene Head Strap: Polyester, Lycra Ventex®-Valve: Natural Rubber

WEIGHT

3700: 20 g **3705:** 28 g

AREAS OF USE

| Level | WEL | Hazard type Examples |
|-------|------|--|
| FFP3 | 20 x | Harmful and carcinogenic dusts, water and oil based mists/ aerosols, biological agents of risk group 2 and 3, CMR-substances |

(WEL = Workplace Exposure Limit)



DATASHEET FFP MASKS PROTECTION AGAINST DUST, MIST & FUMES



TESTING ACCORDING TO EN 149:2001 + A1:2009

Total inward leakage

Ten test subjects perform a variety of exercises. During the exercises the amount of test aerosol that penetrates the filter, face seal and valve are sampled. The total inward leakage of 8 out of 10 test subjects shall not exceed the following levels:

| Category | max. total inward leakage | |
|----------|---------------------------|--|
| FFP3 | 2 % | |

The filter penetration after loading the filter with 120 mg paraffin oil according to EN 149:2001 + A1:2009 shall not exceed the following levels:

| Category | max. filter penetration | |
|----------|-------------------------|--|
| FFP3 | 1 % | |

Flammability

4 respirators are passed through a 800°C (+/- 50°C) flame with a speed of 6 cm/s. After passing through the flame the respirator has to self-extinguish.

Breathing Resistance

The breathing resistance produced by the filter of the respirator is tested at an airflow of 30 l/min and 95 l/min.

| Category | max. breathing resistance according to EN 149 | |
|----------|---|------------|
| | 30 l / min | 95 l / min |
| FFP3 | 1,0 mbar | 3,0 mbar |

INSTRUCTIONS FOR USE

- The user has to be trained and instructed in wearing the mask.
- FFP masks do not protect against gases and vapours.
- The oxygen concentration of the ambient atmosphere should be at least 19,5 % Volume.
- These respirators may not be used if the concentration, type and properties of contaminants in the ambient atmosphere are unknown or at dangerous levels.
- Respirators should be disposed if damaged, if the breathing resistance becomes high due to clogging.
- · Never tamper with, alter or modify the respirator.

INSTRUCTIONS FOR FITTING



1. Pull strap to form a large loop.



 Place respirator on chin and pull loop over head tight to the neck.



3. Pull upper strap and place on back of head.



4. Adjust strap by pulling loop on strap.



5. During breaks unclip strap.



6. Let mask hang around your neck.

INFO

For help on selection and training please contact us. We offer a wide range of training packages and support material.

MOLDEX/METRIC AG & Co. KG Unit 9, Glaisdale Point Off Glaisdale Drive, Bilborough Nottingham. NG8 4GP Tel.: +44 (0)115 985 4288 Fax: +44 (0)115 985 4211 www.moldex-europe.com info@uk.moldex-europe.com

